

## **Yealink SIP IP Phones Change Log of Version 61**

Firmware Version: From x.60.0.120 To x.61.0.70

Applicable Models: SIP-T28/T26/T22/T20/T12

Release Date: November 25, 2011

Mainly released for Call Center field

## 1 New Features

1. Added auto provision code feature.
2. Added Headset Priority feature.
3. Added “Dual Headset” feature.
4. Added “Multicast IP Paging” feature.
5. Added CosmoCom ACD and synchronization feature.
6. Added “Music on hold server” feature.
7. Added SNMP feature.
8. Added display name for call forward feature.
9. Supported Caller-ID display from remote phonebook.
10. Added display XML information from SIP Notify message feature.

## 2 Optimization

1. Added account registration status in the webpage→Status.
2. If you modify something on the webpage during a call, the phone will prompt “Talking...Please update later”, after that it will return to the previous interface.
3. Compatible with IE9 browser.
4. Added CosmoCom type in the “SIP Server Type”.
5. When “Inband” or “RFC2833” was selected in the DTMF type, “How to info DTMF” can’t be configured.
6. Added “PlayHoldTone” and “PlayHoldToneDelay” configuration.
7. Added “DsskeyBlindTran” configuration.
8. Added “DTMFReplaceTran” and “Tran Send DTMF” configuration.
9. Added “AllowMute” configuration to configure whether allow muting during the call.
10. Added “Handset Send Volume” and “Handfree Send Volume” configuration.
11. Added “SendPoundKey” configuration. If “SendPoundKey” is enabled, and select “#” as send key, “##” can be send out.
12. Added “AutoAnswerDelay” configuration in the webpage→Phone→Features.
13. Added “DHCP Option Value” configuration.
14. Auto configuration of first account.
15. Enabled encryption/decryption password.
16. Direct conference function.
17. Username and Password stays in the same interface when login ACD.
18. Transfer cancel configuration.
19. Enter the FWD configuration page when pressing FWD key.
20. The DND, Forward, Anonymous Code will only be sent when the status changed.
21. Added “BLFListBargeInCode” configuration.
22. Display HD characters.
23. Configurable HotDesking feature.
24. Added “NewCall” soft key when holding the call.
25. Auto answer when receiving the special NOTIFY message from Asterisk server.
26. Different dial tone when account is not registered.

27. Emergency incoming call ringtone.
28. Supported configure the register status via auto provision when username is blank.
29. Supported upload multiple language files via auto provision.
30. Supported new Broadsoft network phonebook/calllog format.
31. Added recording conversation duration feature in Action URL.
32. Added recording incoming/outgoing calls feature in Action URL.
33. Deleted custom items such as language/logo after resetting to factory default.
34. Changed default input method to “123” in LDAP phone book.
35. Optimized date display.
36. Increased the length of Xml browser URL to 512.
37. Adjusted display way of display name of second incoming call.
38. Forward international number is configurable now.
39. Prompting login failure message and forbidding to login after 3 failed logins.
40. Webpage will logout automatically after 5 minutes without operation.
41. 802.1x password and AES Key are saved and transmitted as ciphertext.
42. Optimized Broadsoft “No Answer Forward” feature.
43. After enabling “Feature Key Synchronisation”, the phone will not send 302 message to the server when No Answer Forward.
44. It will prompt whether reboot the phone after you changing the SystemLog Level.
45. It will display package time in the Product ID on the LCD.

### 3 Bug Fixes

1. Fixed download error issue when XML phonebook download from the server which used IPV6 address.
2. Fixed the character on the cursor position not display issue on T20 phone. When adding or editing contacts, black list, press left navigation key, the character will not display on the cursor position.
3. Fixed not prompt same name issue when input a contact which has the same name with black list.
4. Fixed not ring group ringtone issue after contact (in this group) deleting custom ringtone.
5. Fixed the issue that ringtone will display blank in the webpage when edit group information after deleting custom group ringtone in IE web browser.
6. Fixed the issue that when T28 has a network conference, and a new call was made by the second account, the network conference account will not be held before new call was answered.
7. Fixed the issue that when the phone use IPV6 address, display name of the third party doesn't changed to caller ID after attended/semi-attended transferring.(It needs server support)
8. Fixed the issue that when update IPV6 address by auto provision, the update will failed if the size of configuration file is larger than certain value.
9. Fixed transfer failed issue in the Broadsoft Call Manager platform.
10. Fixed the issue that after answering or hanging up the incoming call from EHS, the ringtone will last a long time.
11. Fixed the issue that headset doesn't work in the first call after logging ACD.
12. Fixed no ring back tone issue when picking up the handset.
13. Fixed the issue that after T28 answering the call, it still ring ringback tone.
14. Fixed "Transfer on Conference Hang up" doesn't work issue when work with CosmoCom server.
15. Fixed the issue that when pressing TRAN too fast, it will create two calls.
16. Fixed the issue that when blind transfer by DSS Key, the phone sends out transfer message before the server deal with Hold message.
17. Fixed the incorrect LED status of BLA issue.
18. Fixed dial tone can't be heard issue.
19. Fixed the problem of continuous ringing after off-hook of T20.
20. Fixed the problem of repeatedly registers and unable to receive calls or dial of SCA.
21. Fixed the problem that due to INVITE message lacking of genesysid (packaged in REFER message), SIP server is unable relate REFER and INVITE message.
22. Fixed the problem of frequent one-way call fault on ININ platform.
23. Fixed the problem of the failure when in-line initiating conference to out-line.
24. Fixed the problem that call-center is unable to receive DTMF after receiving a call. Fixed unregister issue in the public server.
25. Fixed the issue that the phone can't register to the public server.
26. Fixed the issue that the version field of 802.1X can't be updated according to switch dynamic, so the phone can't be connected by 802.1X.
27. Fixed the phone crash issue when Action URL server was down.

28. Fixed the issue that when MissCall send out the URL, \$remote replaces error.
29. Fixed the issue that expansion modules don't work when connected several expansion modules.
30. Fixed the issue that it doesn't prompt login failed when login ACD with wrong username or password.
31. Fixed the issue that when pressing redial button, it displays forward number.
32. Fixed the issue that when BWCallLogandDir and CallLog are enabled, pressing view key and enter broadsoft network call log after a miss call.
33. Fixed the issue that password dial feature works in the conversation.
34. Fixed the messy codes issue in the updating interface when setting phone language to Korean.
35. Fixed the issue that phone stays in initiating interface after updating V61 firmware via HTTP server.
36. Fixed the issue that phone stays in "Firmware Updating...Please Wait..." interface after upgrading via HTTP auto-provision.
37. Fixed the issue that press "#" cannot dial out the number searching from LDAP phone book.
38. Fixed the issue that BLF doesn't work after rebooting when register to 192.168.1.199 server and configure BLF.
39. Fixed the issue that var user can access to phone after disabling 3-level user access mode. (Restrict var accessing to phone and use Action URI feature)
40. Fixed the issue that client can crack phone's password by telnet with admin/admin. (Restrict admin and guest user permission)
41. Fixed the issue of missing "Public Hold" and "Private Hold" configuration items in DSSKey in T20 LCD.
42. Fixed the issue that when the phone reboot, TLS will register successfully 2 or 3 minutes later.
43. Fixed the LDAP delay issue.
44. Fixed the issue that MAC address changes to 080028320602.
45. Fixed the issue that user level has authority to download bin file by URL.
46. Fixed the issue that after inputting a character in the LDAP dialing interface, there's no any response when pressing Cancelkey.
47. Fixed the issue that telnet password doesn't take effect if you don't reset to factory default.
48. Fixed the issue that the phone will not use the DNS server provided from DHCP server after upgrading to the latest firmware. And the phone will register failed if you don't reboot the phone.
49. Fixed the issue that when sending the message of Music on hold, the IP address in the "c=" line of SDP was incorrect.
50. Fixed the issue that after picking up the call, it will not display Caller ID on the LCD.
51. Fixed Open VPN connection fail issue.
52. Fixed the issue that when there's a second incoming call, there's no any sound after 5 minutes.
53. Fixed the echo issue when there's a second incoming call.

## 4 Instruction(New Features)

### 1. Added auto provision code feature

**Instruction:** Configure following items in the configuration file by auto provision.

```
[ autoprovisionX ] X=1~50
Path = /yealink/config/Setting/autop_code.cfg
Name =
code =
server_address =
user =
password =
AES =
MAC_AES =
```

This feature is for configuring code for auto provision URL. When there's no account registered, press code in idle status, it will prompt a window to ask whether update the phone from the corresponding server\_address. Press "OK" to download the configuration file from this server\_address, press "Cancel" to return to idle status.

**Detail:** Please refer to V61 User Manual for details.

### 2. Added Headset Priority feature

**Path:** Phone → Features → Headset Prior

AutoAnswerDelay	<input type="text" value="1"/>
Headset Prior	Enabled <input type="button" value="v"/>
DsskeyBlindTran	Enabled <input type="button" value="v"/>

**Instruction:** Enabled "Headset Prior", and press "HEADSET" button on the phone, you can answer the call with headset by default. After you answer the call with headset, you can pick up the handset or press Speaker button, and it will change to handset or Speaker mode, but when the phone returns to idle status or reboots, it will switch to headset mode automatically. This feature is disabled by default.

**Detail:** Please refer to V61 User Manual for details.

### 3. Added "Dual Headset" feature

**Path:** Phone → Features → Dual Headset

SRemoteNameFlashTime(seconds)	<input type="text" value="3600"/>
Dual Headset	Enabled <input type="button" value="v"/>
AutoAnswerDelay	<input type="text" value="1"/>

**Instruction:** Enabled "Dual Headset", and press "Headset" on the phone, two headsets can be connected to the phone, one connect to headset port, the other connect to handset port.

When in a conversation, headset with headset port can speak and listen, and headset with handset port can only listen. This feature is disabled by default.

#### 4. Added “Multicast IP Paging” feature

1) Path: Phone→DSS Key→Memory Key/Line Key

Key	Type	Value	Line	Extension
DSS Key 1	Multicast Paging	224.0.1.15:10000	Auto	
DSS Key 2	N/A		Auto	
DSS Key 3	N/A		Auto	

**Instruction:** User can select “Multicast Paging” in the DSS Key, and fill the multicast IP address (For example: 224.0.1.15:10000), then user can start paging with this IP address.

2) Path: Contacts→MulticastIP

Paging Barge: 10  
Paging Priority Active: Enabled

	Listening Address	Label	Priority
1 IP Address	224.0.1.15:10000	test	1
2 IP Address			2
3 IP Address			3
4 IP Address			4
5 IP Address			5
6 IP Address			6
7 IP Address			7
8 IP Address			8
9 IP Address			9
10 IP Address			10

NOTE: multicastipnote

**Instruction:** User can set 10 listening address for receiving paging. The first IP address has the highest priority. The 10<sup>th</sup> IP address has the lowest priority.

In a conversation, whether to receive paging depends on the value of “Paging Barge”. If the value is 10, it means any paging call can barge in the current conversation. If the value is 1, it means only the first paging call can barge in the current conversation.

When “Paging Priority Active” is Enabled and in a paging call, the phone will receive new paging call according to its priority, if the new paging call has the higher priority than current call, it will barge in, otherwise it won't. When “Paging Priority Active” is Disabled, the new paging call will be ignored temporarily.

**Detail:** Please refer to V61 User Manual for details.

#### 5. Added CosmoCom ACD and synchronization feature

Path: Phone→DSS Key→Memory Key/Line Key

**Memory Key >>** ?

Key	Type	Value	Line	Extension
DSS Key 1	ACD		Line 1	
DSS Key 2	N/A		Auto	
DSS Key 3	N/A		Auto	

**Instruction:** Optimized original ACD feature and added ACD synchronization feature. When login the same account both in webpage and on the phone at the same time, their status can be synchronized. This feature needs server support.

**Detail:** Please refer to V61 User Manual for details.

## 6. Added “Music on hold server” feature

**Path:** Account→Advanced→Music on hold server

Early Media  ?

SIP Server Type

Music on hold server

**Instruction:** During a call, if one of party fill a SIP URI in the “Music on hold server”, and hold the call, the other party will be held, and hear the music from this “Music on hold server”. Resume the call, the call will return to normal conversation. This feature needs server support.

**Detail:** Please refer to V61 User Manual for details.

## 7. Added SNMP feature

**Path:** Network→Advanced→SNMP

**SNMP** ?

Active

Port  (0~65535)

Trusted Address

**Instruction:** User can obtain the phone information through server with SNMP feature. It can support 3 server IP address in the “Trusted Address”, and they can be separated by space. It’s disabled by default.

**Detail:** Please refer to V61 User Manual for details.

## 8. Added display name for call forward feature

**Instruction:** When the phone receives a forward call, it can display the name of caller and transferrer on the screen. The display name depends on the message sent from server.

When invite message includes “History-info” header field, it will display the name of the first transferrer. When invite message includes “Diversion” header field, it will display the name of the last transferrer. This feature needs server support.

**Detail:** Please refer to V61 User Manual for details.



## 9. Supported Caller-ID display from remote phone book

**Path:** Phone→Features→SRemoteNameEnable/SRemoteNameFlashTime

AllowMute	Enabled	▼
SRemoteNameEnable	Enabled	▼
SRemoteNameFlashTime(seconds)	3600	
Dual Headset	Disabled	▼

**Instruction:** If the incoming call number was saved in the first remote phonebook, the name can be displayed in the phone screen. It's disabled by default. The update time of remote phonebook can be configured.

## 10. Added display XML information from SIP Notify message feature.

**Path:** Phone→Features→SIP Notify

PushXML Server IP	<input type="text"/>	?
SIP Notify	Enabled	▼
SaveCallHistory	Enabled	▼ ?

**Instruction:** The phone can display XML information from SIP Notify message, it's disabled by default.

**Detail:** Please refer to V61 User Manual for details.

## 5 Instruction(Optimization)

### 1. Added account registration status in the webpage→Status

Path: Web page→Status

Register Status	
Account1	8521@192.168.1.199 : Registered
Account2	1001@10.1.3.45 : Registered
Account3	104@10.1.3.54 : DISABLE
Account4	5553509904@as.mcm.net.mx : Registered
Account5	Unknown
Account6	Unknown

**Instruction:** This feature allows user to know about the accounts’ registration status, the registration status will be updated simultaneously with account registration changed.

### 2. If you modify something on the webpage during a call, the phone will prompt “Talking...Please update later”, after that, it will return to the previous interface.

### 3. Compatible with IE9 browser

**Instruction:** IE9 browser can open the phone webpage normally.

### 4. Added CosmoCom type in the “SIP Server Type”

Path: Web page →Account →Advanced →SIP Server Type

**Instruction:** When selecting CosmoCom type, phone will register to the Backup Outbound Proxy Server when Outbound Proxy Server was unreachable. But if Outbound Proxy Server was recovered, the phone will not go back to register to the original server(Outbound Proxy Server), it will stay register to the Backup Outbound Proxy Server.

**Detail:** Please refer to V61 User Manual for details.

### 5. When “Inband” or “RFC2833” was selected in the DTMF type, “How to INFO DTMF” can’t be configured

Path: Web page →Account →Advanced →DTMF Type/How to INFO DTMF

**Instruction:** When “Inband” or “RFC2833” was selected in the DTMF type, “How to INFO DTMF” will be gray, it can’t be configured.

**6. Added “PlayHoldTone” and “PlayHoldToneDelay” configuration**

**Path:** Webpage → Phone → Features → PlayHoldTone/ PlayHoldToneDelay

MulticastCodec	G722
PlayHoldTone	Enabled
PlayHoldToneDelay	30
AllowMute	Enabled

**Instruction:** User can define whether to play hold tone or not when holding the call, and the tone delay time is configurable. It’s enabled by default and the default delay time is 30s. When the PlayHoldToneDelay is set to 0, the delay time will be 30s by default.

**7. Added “DsskeyBlindTran” configuration**

**Path:** Webpage → Phone → Features → DsskeyBlindTran

Headset Prior	Disabled
DsskeyBlindTran	Enabled
DTMFReplaceTran	Disabled

**Instruction:** When DsskeyBlindTran is enabled, calls will be blind transferred when pressing Dsskey set as Transfer, otherwise calls will be attended-transferred. It’s enabled by default.

**8. Added “DTMFReplaceTran” and “Tran Send DTMF” configuration**

**Path:** Webpage → Phone → Features →DTMFReplace Tran/Tran Send DTMF

DsskeyBlindTran	Enabled
DTMFReplaceTran	Disabled
Tran Send DTMF	
SendPoundKey	Disabled

**Instruction:** When enabled “DTMFReplaceTran” and fill a number to the “Tran Send DTMF”, the DTMF number will be sent out when pressing Tran key, and transfer function will be ineffective. This feature is for limiting user using transfer function. Default setting of neutral firmware is disabled.

**9. Added “AllowMute” configuration to configure whether allow muting during the call**

**Path:** Webpage → Phone → Features → AllowMute

PlayHoldToneDelay	30
AllowMute	Enabled
SRemoteNameEnable	Disabled

**Instruction:** User can configure whether allow muting during the call or not. Default setting is Enabled. When the function is enabled, conversation could be muted when pressing Mute key, and Mute Key will be ineffective if disabled.

## 10. Added “Handset Send Volume” and “Handfree Send Volume” configuration

Path: Webpage → Phone → Features → HandsetSend Volume/Handfree Send Volume

Headset Send Volume (1~53)	<input type="text" value="29"/>	
Handset Send Volume (1~53)	<input type="text" value="27"/>	
Handfree Send Volume (1~53)	<input type="text" value="39"/>	

**Instruction:** These two configuration items enable user to configure the sending volume of handset and handfree mode.

## 11. Added “SendPoundKey” configuration

Path: Webpage → Phone → Features → SendPoundKey

Tran Send DTMF	<input type="text"/>
SendPoundKey	<input type="text" value="Disabled"/>
Fwd International	<input type="text" value="Enabled"/>

**Instruction:** If enable “SendPoundKey”, and select “#” as send key, “##” can be send out.

## 12. Added “AutoAnswerDelay” configuration

Path: Webpage → Phone → Features → AutoAnswerDelay

Dual Headset	<input type="text" value="Disabled"/>
AutoAnswerDelay	<input type="text" value="1"/>
Headset Prior	<input type="text" value="Disabled"/>

**Instruction:** The function enables user to configure auto answer delay (range from 1~4s). Default setting is 1s.

## 13. Added “DHCP Option Value” configuration

Path: Webpage → Upgrade → Advanced → DHCP Option Value

Custom Option Type	<input type="text" value="String"/>	
DHCP Option Value	<input type="text" value="yealink"/>	
URL	<input type="text"/>	

**Instruction:** The function enables user to configure DHCP option value, and DHCP server can identify the phone type. Default setting is yealink.

**Detail:** Please refer to V61 User Manual for details.

## 14. Auto configuration of first account

**Instruction:** The User name and Register name of the first account will be auto configuration when the phone is upgraded or reset to factory default. This feature is disabled by default.

**Form:** z9hG4bK+local phone MAC, no spaces in between. If MAC address is 001565113068, then User name and Register name are both z9hG4bK001565113068.

**15. Enabled encryption/decryption password**

**Instruction:** The function enables user to encrypt or decrypt the password. When setting EnLock = 0, password is saved to phone as cleartext. And EnLock = 1, password is saved as ciphertext. Default setting of neutral firmware is EnLock = 1, to enhance password security.

**16. Direct conference function**

**Path:** Webpage → Phone → DSS Key/EXT key

Memory Key >> ?

Key	Type	Value	Line	Extension
DSS Key 1	Conference	<input type="text"/>	Auto	<input type="text"/>
DSS Key 2	N/A	<input type="text"/>	Auto	<input type="text"/>
DSS Key 3	N/A	<input type="text"/>	Auto	<input type="text"/>

**Instruction:** When setting DSS Key Type as Conference, Value textbox is editable. Press DSS Key and conference to the third party during a conversation, the third party will enter conference directly when answering the phone. In idle status the key works as speed dial.

**Detail:** Please refer to V61 User Manual for details.

**17. Username and Password stays in the same interface**

**Instruction:** When setting DSS Key Type as ACD, pressing the DSS key to enter ACD login interface. Username and password input textbox stays in the same interface.

**18. Transfer cancel configuration**

**Instruction:** During a conversation, press Transfer and Cancel key, the phone will return to previous conversation interface. It's unnecessary to press Resume. The function is configurable, default setting of neutral firmware is disabled.

**19. Enter the FWD configuration page when pressing FWD key.**

**Instruction:** Pressing “TRAN” hardkey or DSS key(Forward) will enter the FWD configuration page on the LCD screen, regardless of FWD status is enabled or disabled. And you can configure Always/Busy/No Answer forward directly as you want. The function is configurable, default setting of neutral firmware is disabled.

**20. The DND, Forward, Anonymous Code will only be sent when the status changed.**

**Instruction:** The DND、Forward、Anonymous code will only be sent when the status changed. The code will not be sent when the phone power-on.

**21. Added “BLFListBargeInCode” configuration**

**Path:** Webpage → Account → Advanced → BLFListBargeInCode

BLF List Code	<input type="text"/>	?
BLFListBargeInCode	<input type="text"/>	?
Shared Line	Disabled	?

**Instruction:** User can fill Bargein code in the “BLFListBargeInCode” field, and fill Pick up code in the “BLF List Code” field. The phone will send different feature codes according to the led status of BLF list.

In a conversation, pressing BLF List key will barge in the call. When there’s an incoming call, pressing BLF List key will pick up the call.

**Detail:** Please refer to V61 User Manual for details.

## 22. Display HD characters

**Instruction:** When the phone uses G722 codec, it will display HD characters at the lower right corner of the LCD interface (the start of the second line in T20).

## 23. Configurable HotDesking feature

**Instruction:** The function enables user to configure the phone on whether to hide or display the options of the register guide (Register Name, User Name, Password, Sip Server and Outbound) when power on and press DSS Key. And the HotDesking account information can be configured from the webpage or LCD screen (The HotDesking account is the first account in the webpage or LCD screen).

Configure following items via auto-provision

Power on:

[ HotDesking\_StartUp ] (Configure display items when enabled Logon Wizard and power on)

path = /yealink/config/Setting/Setting.cfg

RegisterName = (0 stands for hiding this item, 1 stands for displaying this item. The default value is 1)

UserName = (0 stands for hiding this item, 1 stands for displaying this item. The default value is 1)

Password = (0 stands for hiding this item, 1 stands for displaying this item. The default value is 1)

SipServer = (0 stands for hiding this item, 1 stands for displaying this item. The default value is 1)

Outbound = (0 stands for hiding this item, 1 stands for displaying this item. The default value is 1)

Pressing DSS Key:

[ HotDesking\_Dsskey ]

path = /yealink/config/Setting/Setting.cfg

RegisterName = (0 stands for not deleting original information, 1 stands for deleting original information and displaying this item. The default value is 1)

- UserName =** (0 stands for not deleting original information, 1 stands for deleting original information and displaying this item. The default value is 1)
- Password =** (0 stands for not deleting original information, 1 stands for deleting original information and displaying this item. The default value is 1)
- SipServer =** (0 stands for not deleting original information, 1 stands for deleting original information and displaying this item. The default value is 1)
- Outbound =** (0 stands for not deleting original information, 1 stands for deleting original information and displaying this item. The default value is 1)

**Detail:** Please refer to V61 User Manual for details.

#### 24. Added “NewCall” softkey when holding the call

**Instruction:** Added “NewCall” soft key on Hold interface, so user can make a new call directly.

#### 25. Auto answer when receiving the special NOTIFY message from Asterisk server


**Instruction:** The phone will be auto answered on speaker mode when received special NOTIFY message from Asterisk server.

#### 26. Different dial tone when account is not registered

**Instruction:** According to different dial tones, user can see whether current account has been registered. The dial tone frequency of unregistered is: 440/250, 0/250, 440/250, 0/250. The function is configurable, and default setting of neutral firmware is disabled.

#### 27. Emergency incoming call ringtone

**Path:** Webpage → Phone → Preference



**Instruction:** Emergency ringtone is added. When receiving Invite message includes DS-CALL : type emergency header, the phone will play emergency ringtone. And when Invite message does not include DS-CALL: type emergency header, the phone plays regular ringtones.

#### 28. Supported configure the register status via auto provision when username is blank

**Instruction:** When the configuration file for auto provision is with blank username, while account status is enabled, account can be activated. The function is configurable, and default setting of neutral firmware is enabled.

#### 29. Supported upload multiple language files via auto-provision

**Configure Path:** Configure following items via auto-provision

```
[ Lang ]  
path = /tmp/download.cfg  
server_addr_num= N    (N means the number of uploading files)  
server_address1=  
server_address2=  
server_address3=  
...  
server_addressN=
```

**Instruction:** User can upload multiple language files via auto-provision.

**Detail:** Please refer to V61 User Manual for details.

### 30. Supported new Broadsoft network phonebook/calllog format

**Instruction:** The phone is compatible with the format of new Broadsoft network phonebook/calllog.

The function is configurable, default setting of neutral firmware is disabled.

### 31. Added recording conversation duration feature in Action URL

**Instruction:** The function supports variable \$duration in Action URL for recording conversation duration.

**Detail:** Please refer to V61 User Manual for details.

### 32. Added recoding incoming/outgoing calls feature in Action URL

**Instruction:** The function supports variable \$callDirection in Action URL for recording incoming/outgoing calls.

**Detail:** Please refer to V61 User Manual for details.

### 33. Deleted custom items such as language/logo after resetting to factory default

**Instruction:** The phone will delete custom items such as language, ringtone and logo after resetting to factory default.

### 34. Changed default input method to “123” in LDAP phone book

**Instruction:** The default input method is changed to “123” in the LDAP interface of dialing and returning from searching.

### 35. Optimized date display

**Instruction:** Move the date display icon to the right by 3 pixels on T28 LCD screen, to make the screen more aesthetic.

### 36. Increased the length of Xml browser URL to 512

**Instruction:** The maximum length of XML browser URL is increased to 512 bytes.

### 37. Adjusted display way of display name of second incoming call

**Instruction:** Due to the phone can't display a long display name fully, now the display name of second incoming call displays home-left.



### 38. Forward international number is configurable now

**Configure Path:** Configure following items via auto-provision

[Forward International]

path = /Yealink/config/Features/Forward.cfg

Number = (This is for Configuring prefix of international number, the default is 00, It can be configured as string)

**Instruction:** In the previous firmware, user can only configure whether to forward to the international number start with "00". Now the prefix of international number is configurable, and this feature can only be configured via auto-provision.

**Detail:** Please refer to V61 User Manual for details.

### 39. Prompting login failure message and forbidding to login after 3 failed logins

**Instruction:** If input the invalid username or password in login windows for 3 times, the webpage will prompt "Please contact your support team or try again 3 minutes later." As followed:

**You are not authorized to access the web interface.**

Please contact your support team or try again 3 minutes later.

---

HTTP 401

### 40. Webpage will logout automatically after 5 minutes without operation

**Path:** Webpage → Phone → Features → ReLogOffTime(1~1000 minutes)

The screenshot shows a configuration panel with the following elements:

- 'Fwd International' dropdown menu set to 'Disabled'.
- 'ReLogOffTime(1~1000 minutes)' text input field containing the value '5', which is highlighted with a red rectangular box.
- 'Use Logo' dropdown menu set to 'Custom Logo'.
- 'Del' button and a help icon (question mark in a circle).

**Instruction:** The phone webpage will logout automatically over certain time without operation. The time is configurable.

### 41. 802.1x password and AES Key are saved and transmitted as ciphertext

**Path1:** Webpage → Network → Advanced → MD5 Password

The screenshot shows a configuration panel for '802.1x' with the following elements:

- '802.1X Mode' dropdown menu set to 'Disabled'.
- 'Identity' text input field.
- 'MD5 Password' text input field containing masked characters (dots), highlighted with a red rectangular box.

**Path2:** Webpage → Upgrade → Advanced → Password/Common AES Key/MAC-Oriented AES Key

Account  ?

Password  ?

Common AES Key  ?

MAC-Oriented AES Key  ?

Zero Active  ?

**Instruction:** 802.1x password and AES Key are saved and transmitted as ciphertext.

#### 42. Optimized Broadsoft “No Answer Forward” feature

**Path:** Webpage → Phone → Features → After Ring Time (seconds)

**No Answer**  On  Off

After Ring Time(seconds)  ?

Target  ?

On Code  ?

Off Code  ?

**General Information:**

Call Waiting  ?

Call Waiting Tone  ?

Auto redial  ?

Key As Send  ?

Reserve # in User Name  ?

Button Sound  ?

Send Sound  ?

**Instruction:** On Broadsoft server, “After Ring Time” is calculated by ring times. While in Yealink phones, “After Ring Time” is calculated by ring time(seconds). Now it changed to following ways in V61.

1. Configure ring times on Broadsoft server, and the period is 6 seconds each time.
2. Configure ring time (seconds) on phones.
3. To sync phone with server, the equation should be “Time on Server” = 6\* ”Times on Phone”

#### 43. After enabling “Feature Key Synchronisation”, the phone will not send 302 message to the server when No Answer Forward

**Configure Path:** Configure following items via auto-provision

[Forward]


path = /Yealink/config/Features/Forward.cfg

UseLocalFwd =

**Instruction:** When UseLocalFwd=0 and “Feature Key Synchronisation” feature is enabled, the phone will not send 302 message to the server when “No Answer Forward” is enabled. Instead, the server will transfer automatically. When UseLocalFwd=1, the phone will send 302 message to the server. The default setting is 1.  
This feature can only be configured via auto-provision.

**44. It will prompt whether reboot the phone after you changing the System Log Level.**

**Path:** Webpage → Upgrade → Advanced → SystemLog Level



**Instruction:** After changing System Log Level and confirm, it will prompt “System Log Level has been changed, do you want to reboot?” in the webpage. Click OK to reboot the phone and the configuration will take effect. Click Cancel, the phone will not reboot, and the configuration will not take effect until the phone reboot.

**45. It will display package time in the Product ID on the LCD.**

**Path:** Phone LCD → Menu → Status → More... → Phone → Product ID

**Instruction:** It will display package time in the Product ID on the LCD, the format is: XXXX-XXXX-XXXX (Year-Date-Hour) , for example: 2011-1118-1906 .